



ALUMINUM PRODUCT TECH TIPS

Thank-you for your purchase.

We designed our *Thermal Square Bump Fin*® to be not only a unique, industry leading fin but to provide superior strength and cooling for your Industrial Cooling needs.

Please follow the tech tips to ensure trouble free and leak free results:

- With our T-Bar core you MUST weld over the wire holes
- Be sure to ground the core before welding. Do not ground your new core to the workbench
- Preparation is key, be sure to clean, degrease and wire brush your welding area
- Do not use too much heat as this may cause tube to header leaks

WWW.THERMALSOLUTIONSMFG.COM